

Bevel Seat Fittings

Description	Bradford	Alfa Laval	Swagelok / Jensen	Topline	VNE	Waukesha
Short PBS Ferrule	14PRF	14PRFS	14WF	14PRF	14PR	14PRF
Long PBS Ferrule	14A	L14A	14A	L14A7	14A	14A
Recessed PBS Ferrule	14	14	14		14	14
Light Tank Spud PBS Ferrule	14WL	14WL	14WL	14WL	14WL	14WL
Recessless PBS Ferrule	14R	14R	14R	14R	14R	14R
Heavy Tank PBS Ferrule	14W	14W	14W	14W	14W	14W
Reducing PBS Weld Ferrule						
Reducing PBS Ferrule (Ecc.)						
Short TBS Ferrule	15TRF	15TRFS	15WF	15TRF	15TR	15TRF
Long TBS Ferrule	15A	L15A	15A	L15A7	15A	15A
Recessed TBS Ferrule	15	15	15		15	15
Light Tank Spud TBS Ferrule	15WL	15WL	15WL	15WL	15WL	15WL
Recessless TBS Ferrule	15R	15R	15R	15R	15R	15R
Heavy Tank TBS Ferrule	15W	15W	15W	15W	15W	15W
TBS x Male NPT Adapter	21	21	21	21	21	21
TBS x Female NPT Adapter	22	22	22	22	22	22
PBS x Male NPT Adapter	14-19		14-19	14-19	14-19	21-14
PBS x Female NPT Adapter	14-18		14-18	14-18	14-22	22-14
Reducing PBS x Female NPT			31-18F	31-18F		
Reducing PBS x Male NPT			31-19F	31-19F		
PBS Tygon Hose Adapter	14AHT	14AHT	14AHT	14AHT	14AHT	14AHT
PBS Rubber Hose Adapter	14AHR	14AHR	14AHR	14AHR	14AHR	14AHR
PBS Brewery Hose Barb			14AHRB			
TBS Tygon Hose Adapter	15AHT	15AHT	15AHT	15AHT	15AHT	15AHT
TBS Rubber Hose Adapter	15AHR	15AHR	15AHR	15AHR	15AHR	15AHR
TBS Brewery Hose Barb			15AHRB			
TBS x TBS 90	B2C		2C	2C	2C	2C
TBS x PBS/Nut 90	B2F		2F	2F	2F	2F
PBS/Nut x PBS/Nut 90	B2E		2E	2E	2E	2E
Reducing TBS x PBS 90			2F-31	2F-31		2F-31
Reducing TBS x PBS 90 (Ecc)			2F-32			2F-32
TBS x PBS/Nut 45	B2P		2P	2P	2P	2P
TBS x TBS 45	B2K		2K	2K	2K	2K
PBS/Nut x PBS/Nut Concentric	B31-14F		31-14F	31-14F	31-14F	31-14F
PBS x TBS Concentric	B31-15F		31-15F	31-15F	31-15F	31-15F
TBS x PBS/Nut Concentric	B31-TP		31TP	31TP	31TP	31TP
TBS x TBS Concentric	B31-TT		31TT	31TT	31TT	31TT

Bevel Seat Fittings

Description	Bradford	Alfa Laval	Swagelok / Jensen	Topline	VNE	Waukesha
PBS x TBS Eccentric	B32-15F		32-15F	32-15F	32-15F	32-15F
PBS/Nut x PBS/Nut Eccentric	B32-14F		32-14F	32-14F	32-14F	32-14F
TBS x PBS/Nut Eccentric	B32-TP		32TP		32TP	32TP
TBS x TBS Eccentric	B32-TT		32TT		32TT	32TT
TBS Cross	B9		9	9	9	9
TBS x PBS/Nut Cross	B9A		9A			9A
TBS Tee	B7		7	7	7	7
TBS x TBS x PBS/Nut Tee	B7A		7A	7A	7A	7A
TBS x PBS/Nut x TBS Tee	B7B		7B	7B	7B	7B
TBS Lateral	B28A		28A			
TBS True Y	B28B		28B			
PBS End Cap	16A	16A	16A	16A	16A	16A
TBS End Cap	16AT		16AT			
PBS Thermometer Cap	23B		23B	23B	23B	23B
Blind Hex Cap			151			
Hex Nut	13H	13H	13H	13H	13H	13H
Aluminum Hex Wrench	25H		25H	25H		25H
Double Sided Hex Wrench	25H					25HA
TBS x TBS Tube Assembly	17C		17C			
TBS x PBS/Nut Tube Assembly	17D		17D			
PBS/Nut x Pbs/Nut Tube Ass.	17E		17E			
Reducing PBS x TBS Tube Ass.			17F			
Red. PBS x TBS Tube (Ecc)			17G			
Reducing PBS x PBS Tube Ass.			17H			
Red. PBS x PBS Tube (Ecc)			17K			
Bevel Seat Gaskets	40BS	ST40	J40			